



Designer Décor® Collection

by Mattress Safe®

Avant - Garde Solutions for the Box Spring

QuickWrap®

Quick and Easy Install No Mattress Removal Needed

This decorative box spring wrap is a cut above the rest. An upscale design without decking is secured with elastic edges on the top and the bottom, combining style with a simple, fitted solution.

- ◆ No Visible Seams
- ◆ Tailored Fit that Maintains Position
- ◆ Smooth Contoured Corners & Sidewalls
- ◆ Secured with Elastic Completely Around the Top and Bottom Edges



How to Install

Easy 1-2-3 Installation



1 Pull the white stretch knit section behind the head of mattress over the box spring. Secure corners.



2 Pull the bottom of QuickWrap® up and over the mattress and down to the foot of box spring. Secure corners.



3 Beginning from head to foot, adjust the QuickWrap® to ensure a secure fit.

Testing Standards for the Flammability of Mattress Safe® Fabrics.
Shantung -100% Polyester FR Hybrid Passes Chapter 10 of NFPA 701-2010 & CA701
Sawgrass -100% Polyester FR Hybrid Passes Chapter 10 of NFPA 701-2010 & CA701
Stretch Knit -100% Polyester Stretch Knit Passes CFR Title 16 Part 1632 (FF4-72)

"Patent Pending"


Sawgrass Graphite

Our Signature Stock Colors with Designer Fabrics

Shantung *Classic Silk Rendition*



Savile™ *Distinguished Woolen Appearance*



Sawgrass *Refined Linen Look*



MSI202501



Distributed by:



1-800-323-5686

ch-supplies.com




Designer Décor® Collection

by Mattress Safe®

Avant - Garde Solutions for the Box Spring

Properly Measuring Your Box Spring

It is important to properly measure your box spring. **The QuickWrap® is made especially according to your specifications and cannot be returned or exchanged.** Please use the following guidelines to measure correctly.



Width: Measure the width (in inches) of the box spring from side to side to the nearest 1/4 inch. **For Split King box springs, measure the width as one unit.*

Length: Measure the length (in inches) from the head of the box spring to the foot of the box spring to the nearest 1/4 inch.

Depth: To measure the height of the box spring, (measure in inches) from the bottom of the box spring to the top to the nearest 1/4 inch.

Sawgrass

Product Name	Mfr Item Number	Material Number
QuickWrap, Full XL, 9" Deep, Sawgrass	DQKW-LFL 9 SG CRML	1125687
QuickWrap, Queen, 9" Deep, Sawgrass	DQKW-QN 9 SG CRML	1125696
QuickWrap, King, 9" Deep, Sawgrass	DQKW-KG 9 SG CRML	1125694
QuickWrap, Hotel K, 9" Deep, Sawgrass	DQKW-HKG 9 SG CRML	1125691

Shantung

Product Name	Mfr Item Number	Material Number
QuickWrap, Full XL, 9" Deep	DQKW-LFL 9 SH	1125649
QuickWrap, Queen, 9" Deep	DQKW-QN 9 SH	1125646
QuickWrap, King, 9" Deep	DQKW-KG 9 SH	1125642
QuickWrap, Hotel K, 9" Deep	DQKW-HKG 9 SH	1125645

Mattress and Box Spring Sizes

Mattresses and box springs can vary slightly in size.

Long Full 52-54"W x 78-80"L

Queen 58-60"W x 78-80"L

King (combined box springs) 74-76"W x 78-80"L

Hotel King (combined box springs) 70-72"W x 78-80"L

Depths:

5" will fit box springs with a height of 5" to 6.5"

9" will fit from 6.75" to 9.5"